





RPlate Installation Consumables List

<p>Posi-Taps: For tapping into existing wires http://www.posi-products.com/dealer.cfm</p>	 <p>ZWD-PTA1012Y-150 Posi-Tap® 10-12 ga. 150 pc Bag OEM# EX-350Y Bulk PTA1012Y AC/DC 600VAC</p> <p>ZWD-PTA1618-150 Posi-Tap® 14-16 ga. 150 pc Bag OEM# EX-150B Bulk PTA1618 AC/DC 600VAC</p>
<p>5 AMP Fuse - ATM5-25 www.MetraDealer.com</p>	
<p>Fuse Holder- ATFH18MC-10 www.MetraDealer.com</p>	
<p>Zip Ties - BCT8-1, BCT14 www.MetraDealer.com</p>	

<p>Red Nylon Ring Terminal 22-18 Gauge ¼ inch RNRT14</p> <p>www.MetraDealer.com</p>	
<p>Red Nylon Ring Terminal 22-18 Gauge ⅜ inch RNRT38</p> <p>www.MetraDealer.com</p>	
<p>Red Nylon Butt Connector - RNBC-1</p> <p>www.MetraDealer.com</p>	
<p>Crimp Cap Long Neck Nylon 16-14 Gauge CCL1614-1</p> <p>www.MetraDealer.com</p>	
<p>ATR Dual Add a Fuse - Package of 10 - ATRDT</p> <p>www.MetraDealer.com</p>	
<p>5 AMP 2-leg ATR Fuse - 5PK - ATR5-5</p> <p>www.MetraDealer.com</p>	

18 Gauge 2 conductor wire 1000 ft
18-2C-1000-GRY

www.MetraDealer.com

